

Industrial Evolution Pty Ltd

Unit 27/159 Arthur Street Homebush West 2140 NSW

> TEL +61 2 9763 5300 FAX +61 2 9763 5399

ABN 13 108 256 766

www. industrial evolution. com. au

Installation Instructions

2

Hino FD 500 (2021+) In Dash Mount





Step Instructions

1 Remove indicated panel from the passenger side dash, including 2 x screws.





Remove passenger side vent.







Industrial Evolution Pty Ltd

Unit 27/159 Arthur Street Homebush West 2140 NSW

> TEL +61 2 9763 5300 FAX +61 2 9763 5399 ABN 13 108 256 766

www.industrialevolution.com.au

3 Loosen and remove plastic trimming and 1 x cable as shown.







4 Remove screws as indicated, then install upper bracket.







5 Install the lower bracket.



6 Using a sharp blade, carefully shave the indicated plastic extrusion from the internal dash piece.







Industrial Evolution Pty Ltd

Unit 27/159 Arthur Street Homebush West 2140 NSW

> TEL +61 2 9763 5300 FAX +61 2 9763 5399 ABN 13 108 256 766

www.industrialevolution.com.au

7

Restore previously removed cable and dash pieces.









8

Restore side panelling and screws.





9

Install front bracket using 4x countersunk screws provided.



If you have any issues or questions, please contact us. **Industrial Evolution**