

Installation Instructions

Hyundai Santa Fe (2018+)



Step

Instructions

1

Lever and remove plastic cover beneath A/C controls.



2

Remove 2x screws.



3

Hand pull and remove and unplug A/C unit.



4

Lever and remove A/C vents starting from one corner across.



5

Remove 2x screws.



- 6 Lever and remove upper plastic cover, as shown starting from the notch in the plastic.



- 7 Remove 2x screws.



- 8 Lift digital display unit and place under as shown.



9

Replace 4x screws, removed in Step 5 and Step 7.



10

Replace upper plastic cover and A/C vents.



11

Place lower bracket, as shown.



12

Plug in and replace A/C control unit.



13

Use 2x self tapping screws provided, and replace plastic cover removed in Step 1.



14

Install front bracket using 4x countersunk screws provided.



If you have any questions or issues with installation, please contact us.
Industrial Evolution